

Rotor Contact Indicator (RCI)



Features

- Alligator clip connection for easy attachment
- 0V output for open circuit, 9V output upon closure
- Adapts to standard Teledyne QUIKLOOK cable set
- Fused connections for safe operation of QUIKLOOK
- TEDS Sensor Recognition (QUIKLOOK 3-FS ONLY)
- No excitation required

Teledyne LeCroy Test Services (TLTS) Rotor Contact Indicator (RCI) provides the valve tester with a means to monitor unpowered circuits (dry contacts) such as computer points and interlocks as well as assisting with adjustments of critical limit switch settings such as closed torque switch bypass. The RCI provides a usable signal for input to the QUIKLOOK Data Acquisition Systems.

The Rotor Contact Indicator is used with QUIKLOOK Systems and connects directly to the QUIKLOOK cable set.

P/N	System
160009	QL2
160592	QL3-FS

