



TELEDYNE LECROY
Everywhereyoulook™

Net Protocol Suite API Reference Manual

Net Protocol Suite Software Version 4.50

Document disclaimer

The information contained in this document has been carefully checked and is believed to be reliable. However, no responsibility can be assumed for inaccuracies that may not have been detected.

Teledyne LeCroy reserves the right to revise the information presented in this document without notice or penalty.

Trademarks and servicemarks

Teledyne LeCroy is a trademark of Teledyne LeCroy.

Microsoft and Windows are registered trademarks of Microsoft Inc.

All other trademarks are property of their respective companies.

Copyright

Copyright © 2014 Teledyne LeCroy. All Rights Reserved.

This document may be printed and reproduced without additional permission, but all copies should contain this copyright notice.

Contents

1. Introduction	1
2. Functions	1
2.1 Operations on trace file	1
2.2 Packet navigation	1
2.3 Project navigation, recording and jammer.....	1
3. System requirements	2
3.1 Operating System	2
3.2 Required applications	2
3.3 Memory (RAM)	2
3.4 Non-volatile Storage (SDD or Hard Disk)	2
3.5 Connectivity	2
4. Configure Visual Studio	3
4.1 Install Net Protocol Suite	3
4.2 Open Visual Studio.....	3
Select output directory	5
Select input file.....	6
Select directory for include files.....	7
4.3 Creating and using objects	9
5. Understanding the library interface	10
5.1 Initialize/release API	10
APIInitialize().....	10
APIUninitialize().....	10
5.2 Enumerations	11
5.3 Version/Info Methods	11
APIGetVersion ().....	11
APIGetHardwareInfo()	12
5.4 Error handling	13
APIError_GetLastError().....	13
APIError_GetDescription()	13
5.5 Project methods	14
APIProject_create ()	14

APIProject_destroy()	14
APIProject_Open()	14
APIProject_Close()	15
APIProject_Save()	15
APIProject_GetChainCount()	16
APIProject_GetDeviceCount()	16
APIProject_GetPairPortCount()	17
APIProject_GetAnalyzerSettings()	17
APIProject_GetPortConfiguration()	18
APIProject_Assign()	18
APIProject_StartRecording()	19
APIProject_StopRecording()	20
APIProject_StartJammer()	21
APIProject_StartJammers()	22
APIProject_StopJammer()	23
APIProject_StopJammers()	23
APIProject_StartRTS()	24
APIProject_StopRTS()	25
APIJammerManager_GetLibraryTree ()	26
5.6 Analyzer settings	28
APIAnalyzerSettings_create()	28
APIAnalyzerSettings_destroy()	28
APIAnalyzerSettings_GetSegmentBufferSize()	29
APIAnalyzerSettings_SetSegmentBufferSize ()	29
APIAnalyzerSettings_SetTraceFileName ()	30
APIAnalyzerSettings_GetTraceFileName()	30
APIAnalyzerSettings_SetNumberOfSegment ()	31
APIAnalyzerSettings_GetNumberOfSegment ()	31
APIAnalyzerSettings_SetTrigMode()	32
APIAnalyzerSettings_GetTrigMode ()	32
APIAnalyzerSettings_SetTrigFilterSetting ()	33
APIAnalyzerSettings_SetTrigPosition ()	33
APIAnalyzerSettings_GetTrigPosition ()	35
5.7 Trace methods	36
APITrace_create()	36
APITrace_destroy()	36
APITrace_Open()	37
APITrace_Close()	37
APITrace_GetStartDateTime()	37
APITrace_GetEndDateTime()	38
APITrace_GetTriggerDateTime()	38
APITrace_ExportToCSV ()	39

APITrace_ExportToWireshark ()	40
5.8 Packet methods	41
APITracePacket_create()	41
APITracePacket_destroy()	41
APITracePacket_GetTimeStamp()	41
APITracePacket_GetChannel()	42
APITracePacket_GetSpeed()	42
APITracePacket_GetType()	43
APITracePacket_GetData()	44
APITracePacket_GetBookmark()	45
APITracePacket_SetBookmark()	46
5.9 Trace iterator methods	47
APITraceliterator_create()	47
APITraceliterator_destroy()	47
APITraceliterator_HasNext()	47
APITraceliterator_HasPrevious()	48
APITraceliterator_GetNext()	48
APITraceliterator_GetPrevious()	49
APITraceliterator_PeekNext()	49
APITraceliterator_PeekPrevious()	50
APITraceliterator_GetAt()	50
APITraceliterator_GetCount()	50
APITraceliterator_ToBack()	51
APITraceliterator_ToFront()	51
5.10 Examples	52

List of Figures

Figure 1:	Selecting project name.....	3
Figure 2:	Selecting "properties" menu item.	4
Figure 3:	Property pages.....	5
Figure 4:	Defining output directory.	6
Figure 5:	Defining dependencies.....	7
Figure 6:	Defining include directories.	8

List of Tables

Table 1:	Error codes for APIGetVersion ().	11
Table 2:	Error codes for APIGetHardwareInfo ().	12
Table 3:	Error codes for APIProject_create ().	14
Table 4:	Error codes for APIProject_destroy().	14
Table 5:	Error codes for APIProject_Open().	15
Table 6:	Error codes for APIProject_Close().	15
Table 7:	Error codes for APIProject_Save().	16
Table 8:	Error codes for APIProject_GetChainCount().	16
Table 9:	Error codes for APIProject_GetDeviceCount().	16
Table 10:	Error codes for APIProject_GetPairPortCount().	17
Table 11:	Error codes for APIProject_GetAnalyzerSettings().	17
Table 12:	Error codes for APIProject_GetPortConfiguration().	18
Table 13:	Error codes for APIProject_Assign().	19
Table 14:	Error codes for APIProject_StartRecording().	20
Table 15:	Callback Errors for APIProject_StartRecording().	20
Table 16:	Error codes for APIProject_StopRecording().	20
Table 17:	Callback Errors for APIProject_StopRecording().	21
Table 18:	Error codes for APIProject_StartJammer().	21
Table 19:	Callback Errors for APIProject_StartJammer().	22
Table 20:	Error codes for APIProject_StartJammers().	22
Table 21:	Callback Errors for APIProject_StartJammers().	23
Table 22:	Error codes for APIProject_StopJammer().	23
Table 23:	Callback Errors for APIProject_StopJammer().	23
Table 24:	Error codes for APIProject_StopJammers().	24
Table 25:	Callback Errors for APIProject_StopJammers().	24
Table 26:	Error codes for APIProject_StartRTS().	25
Table 27:	Error codes for APIProject_StartRTS().	25
Table 28:	Error codes for APIAnalyzerSettings_create().	28
Table 29:	Error codes for APIAnalyzerSettings_destroy().	29
Table 30:	Error codes for APIAnalyzerSettings_GetSegmentBufferSize().	29
Table 31:	Error codes APIAnalyzerSettings_SetSegmentBufferSize ().	30

Table 32:	Error codes APIAnalyzerSettings_SetTraceFileName ().....	30
Table 33:	Error codes APIAnalyzerSettings_GetTraceFileName().....	30
Table 34:	Error codes for APIAnalyzerSettings_SetNumberOfSegment ().....	31
Table 35:	Error codes for APIAnalyzerSettings_GetNumberOfSegment ().....	31
Table 36:	Error codes for APIAnalyzerSettings_SetTrigMode().....	32
Table 37:	Error codes for APIAnalyzerSettings_GetTrigMode ().....	32
Table 38:	Error codes for APIAnalyzerSettings_SetTrigFilterSetting ().....	33
Table 39:	Error codes for APIAnalyzerSettings_SetTrigPosition ().....	34
Table 40:	Error codes for APIAnalyzerSettings_GetTrigPosition ().....	35
Table 41:	Error codes for APITrace_create().....	36
Table 42:	Error codes for APITrace_destroy().....	36
Table 43:	Error codes for APITrace_Open().....	37
Table 44:	Error codes for APITrace_Close().....	37
Table 45:	Error codes for APITrace_GetStartDateTime().....	38
Table 46:	Error codes for APITrace_GetEndDateTime().....	38
Table 47:	Error codes for APITrace_GetTriggerDateTime().....	38
Table 48:	Error codes for APITrace_ExportToCSV ().....	39
Table 49:	Error codes for APITrace_ExportToWireshark ().....	40
Table 50:	Error codes for APITracePacket_create().....	41
Table 51:	Error codes for APITracePacket_destroy().....	41
Table 52:	Error codes for APITracePacket_GetTimeStamp().....	42
Table 53:	Error codes for APITracePacket_GetChannel().....	42
Table 54:	Error codes for APITracePacket_GetSpeed().....	42
Table 55:	Error codes for APITracePacket_GetType().....	43
Table 56:	Packet type enumeration.....	43
Table 57:	Error codes for APITracePacket_GetData().....	44
Table 58:	Connect/Disconnect.....	44
Table 59:	Ethernet Frame.....	44
Table 60:	FC Frame.....	44
Table 65:	Error codes for APITracePacket_GetBookmark().....	45
Table 61:	Ethernet Ordered Set.....	45
Table 62:	FC Ordered Set.....	45
Table 63:	Auto Negotiation (Packed Format).....	45
Table 64:	Training Sequence.....	45
Table 66:	Error codes for APITracePacket_SetBookmark().....	46
Table 67:	Error codes for APITraceIterator_create().....	47
Table 68:	Error codes for APITraceIterator_destroy().....	47
Table 69:	Error codes for APITraceIterator_HasNext().....	48
Table 70:	Error codes for APITraceIterator_HasPrevious().....	48
Table 71:	Error codes for APITraceIterator_GetNext().....	49
Table 72:	Error codes for APITraceIterator_GetPrevious().....	49

Table 73:	Error codes for APITraceIterator_PeekNext().	49
Table 74:	Error codes for APITraceIterator_PeekPrevious().	50
Table 75:	Error codes for APITraceIterator_GetAt().	50
Table 76:	Error codes for APITraceIterator_GetCount().	51
Table 77:	Error codes for APITraceIterator_ToBack().	51
Table 78:	Error codes for APITraceIterator_ToFront().	51

Net Protocol Suite API

Introduction / Functions / System Requirements Configure Visual Studio / Understanding the Library Interface

1. Introduction

Teledyne LeCroy's Net Protocol Suite API (Application Programming Interface) is a C- based library, which allows you to extract link packets in net trace files, open projects, record traces and run jammer scenarios.

2. Functions

2.1 Operations on trace file

The API supports operations such as setting the trace file name of an project, setting the number of segments, setting the size of segment buffers, running jammer scenarios and recording new traces.

2.2 Packet navigation

The API supports operations such as iterating through trace packets, extracting full raw frame data and any metadata such as time stamps.

2.3 Project navigation, recording and jammer

The API supports operations such as set trace file name of a project, set number of segment, set segment buffer size, run a scenario in jammer, record a new trace.

3. System requirements

3.1 Operating System

Windows XP, Windows 7, Windows 8.1, Windows Server 2003 (32-bit), Windows Server 2008 (R2) and Windows Server 2012.

The latest Service Pack available for the Windows OS in use is required.

It is recommended that the 64-bit Windows version of the Operating Systems is installed, as these allow using more RAM memory than the 32 bit ones.

3.2 Required applications

Microsoft Internet Explorer, version 6 or newer. To view the manuals, datasheets and other documents, you would need to install 'Adobe Acrobat Reader' (<http://get.adobe.com/reader>).

3.3 Memory (RAM)

For improved performance of the software, it is recommended that 16GB of RAM is installed on the host machine. Memory as little as 2GB will still allow the software to function, but would impair its performance.

3.4 Non-volatile Storage (SDD or Hard Disk)

Storage space of 200 MB is required for installing the Net Protocol Suite™ software onto the host machine. Additional storage space is needed to operate the software application and to store recorded data in files. Please remember that storing large captured traces can result in multiple gigabytes of file sizes and can quickly fill your available storage space.

3.5 Connectivity

Teledyne LeCroy recommended a Gigabit (1000-Mbps) Ethernet or a USB 3.0 link for connecting with SierraNet analyzers. At minimum, the host machine should have either a 100/1000-Mbps Ethernet connection to the network or a USB 2.0 port.

If multiple analyzers are daisy-chained and connected to the same host machine, one Ethernet connection or one USB port is required for each analyzer.

Please note that there is no connectivity requirement if the analysis application is used to only view pre-recorded traces.

For tips as for how to improve on the performance of the Teledyne LeCroy analysis system and more specifically on the performance of the software, please refer to the User Manual.

4. Configure Visual Studio

- Perform the following setup to use the library and create your own client applications.

Note: In order for your application to be able to connect to analyzers over Ethernet, your application must run a Windows message loop. The following MSDN article has details about how to do this:

[http://msdn.microsoft.com/en-us/library/windows/desktop/ms644928\(v=vs.85\).aspx](http://msdn.microsoft.com/en-us/library/windows/desktop/ms644928(v=vs.85).aspx)

4.1 Install Net Protocol Suite

1. Download and install Teledyne LeCroy's Net Protocol Suite software.
 - Use the CD that is included with the product.
2. Or download the software from the Teledyne LeCroy website:
<http://teledynelecroy.com/support/softwaredownload/>
3. Select **Support - Software Downloads -Protocol Solutions (Analysis Software)**, and select "Ethernet".

4.2 Open Visual Studio

1. Open Microsoft Visual Studio.
2. Create or open a project.




Figure 1: Selecting project name.

3. Right-click on "Project".

- The Project menu opens.




Figure 2: Selecting "properties" menu item.

4. Select "Properties".

- Project Property Pages opens.




Figure 3: Property pages.

4.2.1 Select output directory

1. In the drop-down menu to the right, select Browse...
2. Find the directory:
 - C:\Users\Public\Documents\LeCroy\Net Protocol Suite\API\SDK\bin
 - Or in the drop-down menu to the right, select Edit.
 - The window "Output Directory" opens.




Figure 4: Defining output directory.

3. Set the path to the output directory. Highlight this text and replace with:

`C:\Users\Public\Documents\LeCroy\Net Protocol Suite\API\SDK\bin`

For Windows XP, the directory is:

`C:\Program Files\LeCroy\Net Protocol Suite\API\SDK\bin`

4.2.2 Select input file

1. Under Configuration Properties, select "Linker", and under that, select "Input".

2. Select "Additional Dependencies".




Figure 5: Defining dependencies.

3. Copy this into the field to the right:

C:\Users\Public\Documents\LeCroy\Net Protocol Suite\API\SDK\Lib\TLNetAPI.lib

- For Windows XP, use this instead:

C:\Program Files\LeCroy\Net Protocol Suite\API\SDK\Lib\TLNetAPI.lib

4.2.3 Select directory for include files

1. Under Configuration Properties, select "C/C++", and under that, select "General".

- Go to "Additional Include Directories".




Figure 6: Defining include directories.

- Enter the following directory:

C:\Users\Public\Documents\LeCroy\Net Protocol Suite\API\SDK\Include

- On the Property Pages window, select "OK" to accept these changes.

- The contents of the include folder are listed below:

TLNetAPI.h: Initializes and releases the API, gets the final internal error code and gets a description of any internal error code functions.

APIProject.h: Declares the project functions.

APIAnalyzerSettings.h: Declares the project's analyzer setting functions.

APIEventHandlers.h: Declares any callback functions that report the status of recording and jammer processes, and reports any process errors or progress.

APITrace.h: Declares all functions.

APITraceIterator.h: Defines trace iterating.

APITracePacket.h: Defines packet navigating.

4.3 Creating and using objects

1. Create a Trace object and open the trace as follows:

```
EAPIErrorCode error_code= API_OK;
APITrace *trace= NULL;
error_code= APITrace_create(trace );
error_code= APITrace_Open( trace , trace_file_name.GetBuffer(0) );
```

2. Create a Trace Iterator and pass the already created Trace Object during its construction.

```
APITraceIterator *trace_itr = NULL;
error_code= APITraceIterator_create( trace , trace_itr );
```

3. That's it! You are now ready to use the different methods of trace and iterator.

```
error_code= APITraceIterator_ToFront( trace_itr );
bool has_next= false;
error_code= APITraceIterator_HasNext( trace_itr , has_next );
if(has_next)
{
    APITracePacket *packet= NULL;
    error_code= APITracePacket_create( packet );
    error_code= APITraceIterator_GetNext( trace_itr , packet );
    EDataType data_type;
    error_code= APITracePacket_getType( packet , data_type );
    .
    .
    .
}
```

4. Don't forget to destroy all created objects.

```
.
.
.
error_code= APITracePacket_destroy( packet );
}
error_code= APITraceIterator_destroy( trace_itr );
error_code= APITrace_destroy( api_trace );
```

5. Understanding the library interface

5.1 Initialize/release API

Initialize and release the API before you use it. Use the following functions to initialize and release the API.

Note: the API can only be initialized/released once per process. Performing multiple initialization/release cycles within a single process is not supported.

Declarations and prototypes

```
TLNetAPI.h
```

5.1.1 APIInitialize()

Prototype

```
APIInitialize()
```

Description

This function initializes the API. It must be called before any other API function calls.

Parameters

None.

Returned value

It always returns zero.

5.1.2 APIUninitialize()

Prototype

```
APIUninitialize()
```

Description

This function releases the API. It must be called after the last API function call. If any API function is called after this, it returns an error code that means API has not been initialized.

Parameters

None.

Returned value

It always returns zero.

5.2 Enumerations

All API enumerations are located in:

SDK/Includes/APIEnumerations.h

5.3 Version/Info Methods

5.3.1 APIGetVersion ()

Prototype

```
APIGetVersion(int *major, int *minor, int *build_no)
```

Description

This function gets the version of the software.

Parameters

major: major software version

minor: minor manor software version

build_no: build number of software

Table 1: Error codes for APIGetVersion ().

API error code	Value	Description
API_EXCEPTION	1	An exception occurred.

5.3.2 APIGetHardwareInfo()

Prototype

```
APIGetHardwareInfo(unsigned short serial_number, unsigned short * product_id)
```

Description

It gets product ID of a device.

Parameters

serial_number: serial number of the board

product_id: product id of the board

If no board with the input serial number exists, the return value is 33. (API_ERROR_INVALID_ARGUMENT). It is possible to get the complete description of the error code by calling APIError_GetLastError() and APIError_GetDescription() functions.

Product id: it can be one of the following values:

Value	Product Id:
0x3102	M408
0x3502	M168
0x1402	M8-4
0x1802	M164

Table 2: Error codes for APIGetHardwareInfo ().

API error code	Value	Description
API_EXCEPTION	1	An exception occurred.

5.4 Error handling

All API functions return an integer value in code from the API ErrorCode enumeration. If any error occurs, a proper error code is returned. (If no code is returned, then that means that no error occurred.) In some cases, more details are available about the error. `APIError_GetLastError()` can be called to return the internal error code. The description of an internal error code, returned by `APIError_GetLastError()`, can be collected by calling `APIError_GetDescription()`.

Declarations and prototypes

```
TLNetAPI.h
```

5.4.1 APIError_GetLastError()

Prototype

```
APIError_GetLastError(): int
```

Description

If any error occurs during an API function call, the function returns an error in code from the `EAPIErrorCode` enumeration. In some cases, more details are available about the error. This function returns the last occurring internal error code. The returned value is an integer. To collect a complete description, call `APIError_GetDescription()`.

Parameters

None.

Returned value

It returns the last internal API error code.

5.4.2 APIError_GetDescription()

Prototype

```
APIError_GetDescription(int error_code, char *error_description,  
                        int max_length_error_description): void
```

Description

It returns a description of an error code.

Parameters

error_code: An integer value as error code.

error_description: An allocated buffer that is passed to collect the description of the error.

max_length_error_description: Maximum length of error description buffer.

Returned value

None.

5.5 Project methods

Declarations and prototypes

```
APIProject.h
```

5.5.1 APIProject_create ()

Prototype

```
APIProject_create(APIProject* *api_project)
```

Description

It creates a new object of project type.

Parameters

api_project: A pointer reference to a created project object.

Table 3: Error codes for APIProject_create ().

API error code	Value	Description
API_ERROR_INSUFFICIENT_MEMORY	3	There is insufficient memory to create a new API object.

5.5.2 APIProject_destroy()

Prototype

```
APIProject_destroy(APIProject* *api_project)
```

Description

This function tries to destroy the input project object. First, it tries to save and close the project. If it cannot save or close, or if the project is in use, this function cannot destroy the input object, and it will return an error. If the project is in use, and API cannot destroy it, nothing happens.

Parameters

api_project: Pointer to the project object created by APIProject_create().

Table 4: Error codes for APIProject_destroy().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.

5.5.3 APIProject_Open()

Prototype

```
APIProject_Open(APIProject *api_project, const char *file_name)
```

Description

It opens a project.

Parameters

api_project: Pointer of the project object created by APIProject_create().

file_name: Null-terminated project file name.

Table 5: Error codes for APIProject_Open().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_OPEN_PROJECT	25	It cannot open the project.

5.5.4 APIProject_Close()**Prototype**

```
APIProject_Close(APIProject *api_project)
```

Description

It disconnects from all boards and closes the opened project by calling APIProject_open().

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

Table 6: Error codes for APIProject_Close().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_CLOSE_PROJECT	23	It cannot close project.
API_ERROR_CAN_NOT_SAVE_PROJECT	24	It cannot save project.
API_ERROR_CAN_NOT_DISCONNECT_FROM_DEVICE	26	It cannot disconnect from a device.

5.5.5 APIProject_Save()**Prototype**

```
APIProject_Save(APIProject *api_project)
```

Description

It saves the project.

Parameters

api_project: Pointer of the opened project object by APIProject_create().

Table 7: Error codes for APIProject_Save().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_SAVE_PROJECT	24	It cannot save the project.

5.5.6 APIProject_GetChainCount()**Prototype**

```
APIProject_GetChainCount(APIProject *api_project, int *chain_count)
```

Description

It returns the number of included chains in the project.

Parameters

api_project: Pointer of the project object opened by APIProject_create().

chain_count: The number of chains in the project.

Table 8: Error codes for APIProject_GetChainCount().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.5.7 APIProject_GetDeviceCount()**Prototype**

```
APIProject_GetDeviceCount(APIProject *api_project, int chain_index,
                           int *device_count)
```

Description

It returns the number of devices in project's chain.

Parameters

api_project: Pointer of the project object opened by APIProject_create().

chain_index: Index of the chain. It is a zero-based index.

device_count: Number of devices in index(th) chain of the project.

Table 9: Error codes for APIProject_GetDeviceCount().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.5.8 APIProject_GetPairPortCount()

Prototype

```
APIProject_GetPairPortCount(APIProject *api_project, int chain_index,
                           int device_index, int *pair_port_count)
```

Description

It returns the number of pair ports supported by a device in a project's chain.

Parameters

api_project: Pointer of the project object opened by APIProject_create().

chain_index: Index of the chain. It is a zero-based index.

device_index: Index of the device. It is zero-based index.

pair_port_count: Number of the device's pair-port in the project.

Table 10: Error codes for APIProject_GetPairPortCount().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.5.9 APIProject_GetAnalyzerSettings()

Prototype

```
APIProject_GetAnalyzerSettings(APIProject *api_project, int chain_index,
                              APIAnalyzerSettings *api_analyzer_settings)
```

Description

It returns the analyzer settings of a specific chain in the opened project.

Parameters

api_project: Pointer of the project object opened by APIProject_create().

chain_index: Index of the chain. It is a zero-based index.

api_analyzer_settings: Refers to the pointer of the analyzer settings of the project's chain_index.

Table 11: Error codes for APIProject_GetAnalyzerSettings().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.

5.5.10 APIProject_GetPortConfiguration()

Prototype

```
APIProject_GetPortConfiguration(APIProject *api_project, int chain_index,
                               int device_index,
                               ELinkConfiguration *port_config)
```

Description

It returns the port configuration of a device in a chain.

Parameters

api_project: Pointer of the project object by APIProject_create().

chain_index: Index of the chain. It is a zero-based index.

device_index: Index of the device. It is a zero-based index.

port_config: Port configuration of the chain's device.

Table 12: Error codes for APIProject_GetPortConfiguration().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.

5.5.11 APIProject_Assign()

Prototype

```
APIProject_Assign(APIProject *api_project, unsigned short serial_number,
                  EConnectionType connection_type, int chain_index,
                  int device_index)
```

Description

It connects to a board and assigns it to a device of a chain in the project. If any board needs to be updated, it returns error codes.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

serial_number: The board's serial number.

connect_type: The board's connection type. It can be USB or TCP.

chain_index: Index of chain. It is a zero-based index.

device_index: Index of device. It is a zero-based index.

Table 13: Error codes for APIProject_Assign().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_SELECTED_DEVICE_IS_NOT_UPDATED	27	The selected device is not updated.
API_ERROR_CAN_NOT_ASSIGN_TO_DEVICE	31	It cannot assign to the selected device.

5.5.12 APIProject_StartRecording()

Prototype

```
APIProject_StartRecording(APIProject *api_project, int chain_index, int
    trigger_settings_count, const char
    **trigger_settings_names, OnTraceCreatedProc
    OnTraceCreated, OnReportRecordingStatusProc
    OnReportRecordingStatus, OnAnalyzerErrorProc
    OnError, int time_out)
```

Description

It starts the recording process.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: Index of chain. It is a zero-based index.

trigger_settings_count: Number of trigger setting names.

trigger_setting_names: Null-terminated Trigger/Filter setting name in the current opened project. If it is Null, the default is used.

event_handler: It refers to a callback function to handle event notifications from the APIs. If it is NULL, then events will not be sent to the client. If the user wants to follow or perform any process during a different recording status, the OnReportRecordingStatus callback function can be used to report changes in the status of the recording process. The OnError callback function is called to report any errors that occur during the recording or uploading processes. When a trace is created, the OnTraceCreated callback function reports that a trace files has been created.

time_out: If the timeout is greater than 0, a timer will begin counting down from the timeout value. If the recording is still in progress when the timer expires, the recording will automatically stop. If the timeout is less than or equal to zero, the recording will continue until stopped by other means.

Table 14: Error codes for APIProject_StartRecording().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_START_RECORDING	30	It cannot start recording process.
API_ERROR_SELECTED_DEVICE_IS_NOT_UPDATED	27	The selected device is not updated.
API_ERROR_INVALID_TRIGGER_NAME	7	Invalid trigger name.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.

The following errors are returned by callback function:

Table 15: Callback Errors for APIProject_StartRecording().

API error code	Value	Description
API_ERROR_RECORDING	16	An error occurred during recording process.
API_ERROR_UPLOADING	17	An error occurred during uploading process.

5.5.13 APIProject_StopRecording()

Prototype

```
APIProject_StopRecording(APIProject *api_project, int chain_index,
                        bool do_not_upload)
```

Description

It stops any recording or uploading process.

Parameters

api_project: Pointer of the opened project object by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

Do_not_upload: If it is true, it does not upload any trace file, or stop uploading if the uploading was started automatically.

Table 16: Error codes for APIProject_StopRecording().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_CAN_NOT_STOP_RECORDING	29	

The following errors are returned by callback function.

Table 17: Callback Errors for APIProject_StopRecording().

API error code	Value	Description
API_ERROR_RECORDING	16	An error occurred during recording process.
API_ERROR_UPLOADING	17	An error occurred during uploading process.

5.5.14 APIProject_StartJammer()

Prototype

```
APIProject_StartJammer(APIProject *api_project, int chain_index, int
device_index, int pair_port_index, const char
*scenario_name, OnReportMonitoringStatusProc
OnReportMonitoringStatus, OnReportJammerStatusProc
OnReportJammerStatus, OnJammerErrorProc OnError);
```

Description

It starts the jammer process.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

device_index: The device's index. It is a zero-based index.

pair_port_index: The pair port's index. It is a zero-based index.

scenario_name: Null-terminated Scenario name. If it is Null, then the project default is used.

event_handler: It refers to a callback function to handle the events. If it is NULL, the events will not be sent to the client.

Table 18: Error codes for APIProject_StartJammer().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_START_JAMMER	13	It cannot start jammer process.
API_ERROR_SELECTED_DEVICE_IS_NOT_UPDATED	27	The selected device is not updated.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_INVALID_PAIR_PORT_INDEX	6	Invalid pair port index.
API_ERROR_INVALID_SCENARIO_NAME	28	Invalid scenario name.

The following errors are returned by callback function.

Table 19: Callback Errors for APIProject_StartJammer().

API error code	Value	Description
API_ERROR_JAMMER	18	An error occurred during jammer process.

5.5.15 APIProject_StartJammers()

Prototype

```
APIProject_StartJammers(APIProject *api_project, int chain_index, int
    device_index, int count, int pair_port_indexes[],
    const char *scenario_names[],
    OnReportMonitoringStatusProc
    OnReportMonitoringStatus[], OnReportJammerStatusProc
    OnReportJammerStatus[], OnJammerErrorProc
    OnError[]);
```

Description

It starts the jammer process on a set of ports. If any port has a problem, it does not stop; it starts to jam another port. It returns the last error code if any exists; otherwise, it returns zero.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

device_index: The device's index. It is a zero-based index.

count: Jammer count.

pair_port_indexes[]: Array of indexes of pair ports. It is a zero-based index.

scenario_names[]: Array of indexes of scenario names. Null terminated Scenario name. If it is Null, project default is used.

event_handler[]: It refers to a callback function to handle the events. If it is NULL, the events will not be sent to the client.

Table 20: Error codes for APIProject_StartJammers().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_START_JAMMER	13	It cannot start jammer process.
API_ERROR_SELECTED_DEVICE_IS_NOT_UPDATED	27	The selected device is not updated.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_INVALID_PAIR_PORT_INDEX	6	Invalid pair port index.
API_ERROR_INVALID_SCENARIO_NAME	28	Invalid scenario name.

The following errors are returned by callback function.

Table 21: Callback Errors for APIProject_StartJammers().

API error code	Value	Description
API_ERROR_JAMMER	18	An error occurred during jammer process.

5.5.16 APIProject_StopJammer()

Prototype

```
APIProject_StopJammer(APIProject *api_project, int chain_index,
                      int device_index, int pair_port_index)
```

Description

It stops the jammer process.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

device_index: The device's index. It is a zero-based index.

pair_port_index: The pair port index. It is a zero-based index.

Table 22: Error codes for APIProject_StopJammer().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_INVALID_PAIR_PORT_INDEX	6	Invalid pair port index.
API_ERROR_CAN_NOT_STOP_JAMMER	12	It cannot stop jammer process.

The following errors are returned by callback function.

Table 23: Callback Errors for APIProject_StopJammer().

API error code	Value	Description
API_ERROR_JAMMER	18	An error occurred during jammer process.

5.5.17 APIProject_StopJammers()

Prototype

```
APIProject_StopJammers(APIProject *api_project, int chain_index,
                       int device_index, int count, int pair_port_indexes[])
```

Description

It stops the jammer process on a set of ports. If any port has a problem, it does not stop and continues to stop jamming other ports. It returns the last error code if any exists. Otherwise it returns zero.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

device_index: The device's index. It is a zero-based index.

count: The jammer count.

pair_port_indexes[]: Array of indexes of pair ports. It is a zero-based index.

Table 24: Error codes for APIProject_StopJammers().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_INVALID_PAIR_PORT_INDEX	6	Invalid pair port index.
API_ERROR_CAN_NOT_STOP_JAMMER	12	It cannot stop jammer process.

The following errors are returned by callback function.

Table 25: Callback Errors for APIProject_StopJammers().

API error code	Value	Description
API_ERROR_JAMMER	18	An error occurred during jammer process.

5.5.18 APIProject_StartRTS()**Prototype**

```
APIProject_StartRTS(APIProject *api_project, int chain_index, int
device_index, const char *log_file_name);
```

Description

It starts the RTS process.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

device_index: The device's index. It is a zero-based index.

log_file_name: User specified CSV file for the RTS log output.

Table 26: Error codes for APIProject_StartRTS().

API error code	Value	Description
IDE_PROJECT_NEW_DEVICE_SELECTED_NOT_UPDATED	27	The selected device is not updated.
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_CAN_NOT_START_RTS	37	Cannot start RTS process
API_ERROR_CAN_NOT_OPEN_LOG_RTS	38	Unable to open user specified log file. Possible file is in use.

5.5.19 APIProject_StopRTS()

Prototype

```
APIProject_StopRTS(APIProject api_project, int chain_index, int
device_index);
```

Description

It stops the RTS process.

Parameters

api_project: Pointer of the project object opened by APIProject_Open().

chain_index: The chain's index. It is a zero-based index.

device_index: The device's index. It is a zero-based index. log_file_name: User specified CSV file for the RTS log output.

Table 27: Error codes for APIProject_StartRTS().

API error code	Value	Description
API_ERROR_INVALID_CHAIN_INDEX	4	Invalid chain index.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.
API_ERROR_CAN_NOT_STOP_RTS	36	Cannot start RTS process

5.5.20 APIJammerManager_GetLibraryTree ()

Prototype

```
APIJammerManager_GetLibraryTree (APIJammerManager *api_jammer_manager,
    JammerLibraryNode* library_tree);
```

Description

It returns the Jammer library in the form of a tree.

Parameters

Parameter Name	Type	Description
api_jammer_manager	APIJammerManager*	Pointer to the APIJammerManager object
library_tree	JammerLibraryNode*	Pointer to a JammerLibraryNode object.

This is a structure that would be filled up on return.

The definition of the JammerLibraryNode which can be found in APIEnumeration.h is as below

```
struct JammerLibraryNode
{
    char*          Name;
    bool           IsGroup;
    int            ChildrenCount;
    JammerLibraryNode* Children;
};
```

The definition of the parameters is as follows

Node Member Name	Description
Name	The name of the node. It can be either a name of scenario/Group. An empty name indicates the root node.
IsGroup	It indicates whether the node is a Group. The value is false if it's a scenario.
ChildrenCount	It indicates the number of child, in case the node is a group. The value is 0 if the node is a scenario.
Children	This is a pointer to its children.

Error codes

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

Example : A C++ example of getting the list of scenario names, and run of your choice

```
void ReturnScenerioNames(JammerLibraryNode* node,
std::vector<std::string>& scenerio_names)
{
    for (int index = 0; index < node->ChildrenCount; ++index)
    {
        auto child = &node->Children[index];
        if (child->IsGroup)
        {
            ReturnScenerioNames(child, scenerio_names);
        }
        else
        {
            scenerio_names.emplace_back(child->Name);
        }
    }
}

// Get all the scenario-names
JammerLibraryNode library_tree;
APIJammerManager_GetLibraryTree(jammer_manager, &library_tree);
ReturnScenerioNames(&library_tree, scenerio_names);
```

```
// Run the desired scenario
for (auto scenerio_name: scenerio_names)
{
if (scenerio_name == "MyScenerioPort1")
    {
        APIProject_StartJammer( Project, 0, 0, 0, scenerio_name.c_str(),
        nullptr, nullptr, nullptr);
        // More logic goes here
    }
}
}
```

5.6 Analyzer settings

Declarations and prototypes

APIAnalyzerSettings.h

5.6.1 APIAnalyzerSettings_create()

Prototype

APIAnalyzerSettings_create(APIAnalyzerSettings* *api_analyzer_settings)

Description

It creates a new analyzer settings object.

Parameters

api_analyzer_settings: It is a pointer reference to created analyzer settings object.

Table 28: Error codes for APIAnalyzerSettings_create().

API error code	Value	Description
API_ERROR_INSUFFICIENT_MEMORY	3	There is insufficient memory to create a new API object.

5.6.2 APIAnalyzerSettings_destroy()

Prototype

APIAnalyzerSettings_destroy(APIAnalyzerSettings* *api_analyzer_settings)

Description

It destroys the created APIAnalyzerSettings object.

Parameters

api_analyzer_setting: Pointer to the APIAnalyzerSettings object.

Table 29: Error codes for APIAnalyzerSettings _destroy().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.

5.6.3 APIAnalyzerSettings_GetSegmentBufferSize()

Prototype

```
APIAnalyzerSettings_GetSegmentBufferSize(APIAnalyzerSettings
                                         *api_analyzer_settings,
                                         int device_index,
                                         int *segment_buffer_size)
```

Description

It returns the size of the segment buffer.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

device_index: Zero-based index of the device.

segment_buffer_size: Segment buffer size (specified in KB).

Table 30: Error codes for APIAnalyzerSettings_GetSegmentBufferSize().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.

5.6.4 APIAnalyzerSettings_SetSegmentBufferSize ()

Prototype

```
APIAnalyzerSettings_SetSegmentBufferSize(APIAnalyzerSettings
                                         *api_analyzer_settings,
                                         int device_index, int segment_size)
```

Description

It sets the size of a segment buffer.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

device_index: Zero-based index of the device.

segment_size: New segment size in Kbytes.

Table 31: Error codes APIAnalyzerSettings_SetSegmentBufferSize ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_SEGMENT_SIZE	9	Invalid segment size.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.

5.6.5 APIAnalyzerSettings_SetTraceFileName ()

Prototype

```
APIAnalyzerSettings_SetTraceFileName(APIAnalyzerSettings
                                     *api_analyzer_settings,
                                     const char* file_name)
```

Description

It sets the file name of the analyzer settings.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

file_name: A null terminate file name of analyzer settings object.

Table 32: Error codes APIAnalyzerSettings_SetTraceFileName ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.6.6 APIAnalyzerSettings_GetTraceFileName()

Prototype

```
APIAnalyzerSettings_GetTraceFileName(APIAnalyzerSettings
                                     *api_analyzer_settings,
                                     char **trace_file_name)
```

Description

It returns the trace file name of the analyzer settings object.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

file_name: Returned trace file name. This pointer must not be deleted or destroyed by the user.

Table 33: Error codes APIAnalyzerSettings_GetTraceFileName().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.6.7 APIAnalyzerSettings_SetNumberOfSegment ()

Prototype

```
APIAnalyzerSettings_SetNumberOfSegment(APIAnalyzerSettings
                                       *api_analyzer_settings,
                                       int segment_number)
```

Description

It sets the number of segments. If the segment buffer size is not valid according to the device property and new segment number, it will change to the valid maximum segment buffer size, depending on the quantity of current segments.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

segment_number: Number of segments.

Table 34: Error codes for APIAnalyzerSettings_SetNumberOfSegment ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_NUMBER_OF_SEGMENT	10	Invalid number of segments.

5.6.8 APIAnalyzerSettings_GetNumberOfSegment ()

Prototype

```
APIAnalyzerSettings_GetNumberOfSegment(APIAnalyzerSettings
                                       *api_analyzer_settings,
                                       int *number_of_segment)
```

Description

It returns the number of segments.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

segment_number: Number of segments.

Table 35: Error codes for APIAnalyzerSettings_GetNumberOfSegment ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.6.9 APIAnalyzerSettings_SetTrigMode()

Prototype

```
APIAnalyzerSettings_SetTrigMode(APIAnalyzerSettings *api_analyzer_settings,
                                ETriggerMode trig_mode)
```

Description

It sets trigger mode.

Parameters

api_analyzer_settings: Analyzer settings pointer.

trig_mode: Trigger mode can be one of these values:

SNAPSHOT	0
PATTERN	1

Table 36: Error codes for APIAnalyzerSettings_SetTrigMode().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_TRIG_MODE	11	Invalid trigger mode.

5.6.10 APIAnalyzerSettings_GetTrigMode ()

Prototype

```
APIAnalyzerSettings_GetTrigMode(APIAnalyzerSettings *api_analyzer_settings,
                                ETriggerMode *trig_mode)
```

Description

It returns trigger mode.

Parameters

api_analyzer_settings: Analyzer settings pointer.

trig_mode: Returns trigger mode.

SNAPSHOT	0
PATTERN	1

Table 37: Error codes for APIAnalyzerSettings_GetTrigMode ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.6.11 APIAnalyzerSettings_SetTrigFilterSetting ()

Prototype

```
APIAnalyzerSettings_SetTrigFilterSetting(APIAnalyzerSettings
                                         *api_analyzer_settings,
                                         int device_index,
                                         const char *trig_setting_name)
```

Description

It sets trigger filter setting.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

trig_setting_name: Null-terminated Trigger/Filter setting name in the currently opened project.

Table 38: Error codes for APIAnalyzerSettings_SetTrigFilterSetting ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_TRIGGER_NAME	7	Invalid trigger name.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.

5.6.12 APIAnalyzerSettings_SetTrigPosition ()

Prototype

```
APIAnalyzerSettings_SetTrigPosition(APIAnalyzerSettings
                                     *api_analyzer_settings,
                                     int device_index, int trig_position)
```

Description

It sets the trigger position.

Parameters

api_analyzer_settings: Analyzer settings pointer.

device_index: Zero-based index of the device.

Trig_position: Project trigger's position. It can be 1 to 99.

Table 39: Error codes for APIAnalyzerSettings_SetTrigPosition ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_TRIGGER_POSITION	8	Invalid trigger position. It must be between 1 and 99.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.

5.6.13 APIAnalyzerSettings_GetTrigPosition ()

Prototype

```
APIAnalyzerSettings_GetTrigPosition(APIAnalyzerSettings
                                     *api_analyzer_settings,
                                     int device_index, int *trig_position)
```

Description

It returns the trigger position.

Parameters

api_analyzer_settings: Pointer of the analyzer settings.

device_index: Zero-based index of the device.

trig_position: Project trigger's position. It can be 1 to 99.

Table 40: Error codes for APIAnalyzerSettings_GetTrigPosition ().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_DEVICE_INDEX	5	Invalid device index.

5.7 Trace methods

Declarations and prototypes

```
APITrace.h
```

5.7.1 APITrace_create()

Prototype

```
APITrace_create(APITrace* *api_trace)
```

Description

It creates a new trace object.

Parameters

api_trace: It is a pointer reference to a created trace object.

Table 41: Error codes for APITrace_create().

API error code	Value	Description
API_ERROR_INSUFFICIENT_MEMORY	3	There is insufficient memory to create a new API object.

5.7.2 APITrace_destroy()

Prototype

```
APITrace_destroy(APITrace* *api_trace)
```

Description

It destroys the created trace object. It does not close the trace file. It calls APITrace_Close() function before destroying the api_trace object.

Parameters

api_trace: Pointer to the trace object.

Table 42: Error codes for APITrace_destroy().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_SAVE_TRACE	21	It cannot save the trace.
API_ERROR_CAN_NOT_CLOSE_TRACE	22	It cannot close the trace.

5.7.3 APITrace_Open()

Prototype

```
APITrace_Open(APITrace *api_trace, const char *file_name)
```

Description

It opens a trace. If trace file needs to be updated, it will be updated and then opened. The update process updates the trace file without creating any backup from the updated trace file.

Parameters

api_trace: Pointer to the trace object.

file_name: Null-terminated string providing the full pathname to the trace file.

Table 43: Error codes for APITrace_Open().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_UPDATE_TRACE	20	It cannot update the trace.
API_ERROR_CAN_NOT_OPEN_TRACE	19	It cannot open the trace.

5.7.4 APITrace_Close()

Prototype

```
APITrace_Close(APITrace *api_trace)
```

Description

It closes the opened trace object. If the trace has any modification, it is saved and then closed.

Parameters

api_trace: Pointer to the trace object.

Table 44: Error codes for APITrace_Close().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_CAN_NOT_SAVE_TRACE	21	It cannot save the trace.
API_ERROR_CAN_NOT_CLOSE_TRACE	22	It cannot close the trace.

5.7.5 APITrace_GetStartDateTime()

Prototype

```
APITrace_GetStartDateTime(APITrace *api_trace, time_t *start_date_time)
```

Description

It returns the start date-time of the trace object.

Parameters

api_trace: Pointer to the trace object.

start_date_time: Start date-time of the trace.

Table 45: Error codes for APITrace_GetStartDateTime().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.7.6 APITrace_GetEndDateTime()**Prototype**

```
APITrace_GetEndDateTime(APITrace *api_trace, time_t *end_date_time)
```

Description

It returns the end date-time of the trace object.

Parameters

api_trace: Pointer to the trace object.

end_date_time: End date-time of the trace.

Table 46: Error codes for APITrace_GetEndDateTime().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.7.7 APITrace_GetTriggerDateTime()**Prototype**

```
APITrace_GetTriggerDateTime(APITrace *api_trace, time_t *trig_date_time)
```

Description

It returns the trigger date-time of the trace object.

Parameters

api_trace: Pointer to the trace object.

trig_date_time: Trig datetime of the trace.

Table 47: Error codes for APITrace_GetTriggerDateTime().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.7.8 APITrace_ExportToCSV ()

Prototype

```
APITrace_ExportToCSV(APITrace *api_trace, const char *csv_file_name,
OnExportProc OnExport)
```

Description

This function export an opened trace file to CSV file.

Parameters

api_trace: trace object

Csv_file_name: csv file name

OnExport: callback function, used to report percentage of exporting process.

```
void OnExport( int progress );
```

This callback function is called to provide status updates on the progress of an export operation. 'progress' is an integer from 0 to 100 that indicates the percentage of completion of the export.

Table 48: Error codes for APITrace_ExportToCSV ().

API error code	Value	Description
API_EXCEPTION	1	An exception occurred.

5.7.9 APITrace_ExportToWireshark ()

Prototype

```
APITrace_ExportToWireshark(APITrace *api_trace, const char
*wireshark_file_name, EAPILinkProtocol api_link_protocol, OnExportProc
OnExport)
```

Description

This function exports an opened trace file to wireshark.

Parameters

api_trace: trace object

Wireshark_file_name: output file name

api_link_protocol: Specifies you want to export Ethernet frames or Fibre channel frames.

It can be one of below values:

```
API_LINK_PROTOCOL_ETHERNET = 0;
```

```
API_LINK_PROTOCOL_FC = 1;
```

OnExport: callback function, used to report percentage of exporting process.

```
void OnExport( int progress );
```

This callback function is called to provide status updates on the progress of an export operation. 'progress' is an integer from 0 to 100 that indicates the percentage of completion of the export.

Table 49: Error codes for APITrace_ExportToWireshark ().

API error code	Value	Description
API_EXCEPTION	1	An exception occurred.

5.8 Packet methods

Declarations and prototypes

```
APITracePacket.h
```

5.8.1 APITracePacket_create()

Prototype

```
APITracePacket_create(APITracePacket* *api_trace_packet)
```

Description

It creates a new trace object.

Parameters

api_trace_packet: It is a pointer reference to a created packet object.

Table 50: Error codes for APITracePacket_create().

API error code	Value	Description
API_ERROR_INSUFFICIENT_MEMORY	3	There is insufficient memory to create a new API object.

5.8.2 APITracePacket_destroy()

Prototype

```
APITracePacket_destroy(APITracePacket* *api_trace_packet)
```

Description

It destroys the created packet object.

Parameters

api_trace_packet: Pointer to the trace object.

Table 51: Error codes for APITracePacket_destroy().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.

5.8.3 APITracePacket_GetTimeStamp()

Prototype

```
APITracePacket_GetTimeStamp(APITracePacket *api_trace_packet,
                             __int64 *timestamp)
```

Description

It returns time stamp of the packet in picoseconds. One picosecond is equal to 1/1000 nanosecond.

Parameters

api_trace_packet: Pointer to the trace packet object.

timestamp: Timestamp of the packet in picoseconds.

Table 52: Error codes for APITracePacket_GetTimeStamp().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.8.4 APITracePacket_GetChannel()

Prototype

```
APITracePacket_GetChannel(APITracePacket *api_trace_packet, int *channel)
```

Description

It returns the packet's channel.

Parameters

api_trace_packet: Pointer to the trace packet object.

channel: Channel of the packet.

Table 53: Error codes for APITracePacket_GetChannel().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.8.5 APITracePacket_GetSpeed()

Prototype

```
APITracePacket_GetSpeed(APITracePacket *api_trace_packet,
                        EAnalyzerSpeed *speed)
```

Description

It returns the packet's speed.

Parameters

api_trace_packet: Pointer to the trace packet object.

speed: Speed of the packet.

Table 54: Error codes for APITracePacket_GetSpeed().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.8.6 APITracePacket_GetType()

Prototype

```
APITracePacket_GetType(APITracePacket *api_trace_packet, EDataType *type)
```

Description

It returns the packet's protocol.

Parameters

api_trace_packet: Pointer to the trace packet object.

type: It returns the type of the packet. The Packet Type enumeration is given below:

ConnectDisconnect	0
EthernetFrame	1
FCFrame	2
EthernetOrderedSet	3
FCOrderedSet	4
AutoNegotiation	5
TrainingSequence	6

Table 55: Error codes for APITracePacket_GetType().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

Table 56: Packet type enumeration.

Packet Type	Value (enum)
Connect/Disconnect	0
Ethernet Frame	1
FC Frame	2
Ethernet Ordered Set	3
FC Ordered Set	4
Auto Negotiation	5
Training Sequence	6

5.8.7 APITracePacket_GetData()

Prototype

```
APITracePacket_GetData(APITracePacket *api_trace_packet,
                      unsigned char* *data, int *data_length)
```

Description

The 'raw_data' parameter will be set to the address of the raw data buffer of the packet. The return value shows the size of the buffer in bytes. The packet object manages the raw data buffer. Do not attempt to manually delete the buffer. The buffer is valid as long as the packet object is alive and the trace is open.

Parameters

api_trace_packet: Pointer to the trace packet object.

data: It will be set to the address of the packet's data buffer.

data_length: Data size in bytes.

- The packet object manages the raw data buffer. Do not attempt to manually delete the buffer. The buffer is valid as long as the packet object is alive and the trace is open.

Table 57: Error codes for APITracePacket_GetData().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

The format for each packet type is as follows. Unless otherwise specified, the byte ordering is little-endian.

Table 58: Connect/Disconnect

DWord	Description
0	Connect: 1/Disconnect: 0

Table 59: Ethernet Frame.

DWord	Description
0	Ethernet Frame
1	Ethernet Frame
2	Ethernet Frame
...	...
N	Ethernet Frame

Table 60: FC Frame

DWord	Description
0	SOF
1	FC Frame
2	FC Frame
...	...
N	EOF

Table 61: Ethernet Ordered Set

DWord	Description
0	Order Set Data (64 bits)
1	
2	Order Set Count

Table 62: FC Ordered Set

DWord	Description
0	Order Set Data (32 bits)
1	Order Set Count

Table 63: Auto Negotiation (Packed Format)

DWord	Description
9	Count

Table 64: Training Sequence

DWord	Description
0	Control Field + Status Fields
1	Count

5.8.8 APITracePacket_GetBookmark()

Prototype

```
APITracePacket_GetBookmark(APITracePacket *api_trace_packet,
                           char* *bookmark)
```

Description

It returns the packet's bookmark.

Parameters

api_trace_packet: Pointer to the trace packet object.

bookmark: Current bookmark of the packet.

Returned value

It returns packet bookmark strings (only the bookmark title). The packet object manages the returned buffers. Do not attempt to manually delete the buffers. The buffers are valid as long as the packet object is alive and the trace is open.

Table 65: Error codes for APITracePacket_GetBookmark().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.8.9 APITracePacket_SetBookmark()

Prototype

```
APITracePacket_SetBookmark(APITracePacket *api_trace_packet,  
                           const char *bookmark)
```

Description

It places a new bookmark on the packet. If the packet already has an existing bookmark, it is replaced with the new one.

Parameters

api_trace_packet: Pointer to the trace packet object.

bookmark: Name of the bookmark.

Table 66: Error codes for APITracePacket_SetBookmark().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9 Trace iterator methods

Declarations and prototypes

```
APITraceIterator.h
```

5.9.1 APITraceIterator_create()

Prototype

```
APITraceIterator_create(APITrace *api_trace, APITraceIterator*
                        *api_trace_iterator)
```

Description

It creates a new trace iterator object. The iterator will be initialized to the beginning of the trace.

Parameters

api_trace: Trace object.

api_trace_iterator: Reference pointer of created iterator object.

Table 67: Error codes for APITraceIterator_create().

API error code	Value	Description
API_ERROR_INVALID_TRACE	14	Invalid API trace object.
API_ERROR_INSUFFICIENT_MEMORY	3	There is insufficient memory to create a new API object.

5.9.2 APITraceIterator_destroy()

Prototype

```
APITraceIterator_destroy(APITraceIterator* *api_trace_iterator)
```

Description

It destroys the created trace iterator object.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

Table 68: Error codes for APITraceIterator_destroy().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.

5.9.3 APITraceIterator_HasNext()

Prototype

```
APITraceIterator_HasNext(APITraceIterator *api_trace_iterator,
                        bool *has_next)
```

Description

It returns true if iteration has more packets when traversing in forward direction; otherwise, returns false.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

has_next: If there is a next packet, it will be true; otherwise it will be false.

Table 69: Error codes for APITraceIterator_HasNext().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.4 APITraceIterator_HasPrevious()**Prototype**

```
APITraceIterator_HasPrevious(APITraceIterator *api_trace_iterator,
                             bool *has_previous)
```

Description

It returns true if iteration has more packets when traversing in backward direction; otherwise, returns false.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

has_previous: If there is any previous packet, it will be true; otherwise it will be false.

Table 70: Error codes for APITraceIterator_HasPrevious().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.5 APITraceIterator_GetNext()**Prototype**

```
APITraceIterator_GetNext(APITraceIterator *api_trace_iterator,
                          APITracePacket *api_trace_packet)
```

Description

It returns the iterator packet and moves the iterator forward.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

api_trace_packet: Next packet container.

Returned value

It returns next packet of iterator and moves the iterator forward.

Table 71: Error codes for APITraceIterator_GetNext().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.6 APITraceIterator_GetPrevious()

Prototype

```
APITraceIterator_GetPrevious(APITraceIterator *api_trace_iterator,
                             APITracePacket *api_trace_packet)
```

Description

It returns previous packet of iterator and moves the iterator backward.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

api_trace_packet: Previous packet container.

Table 72: Error codes for APITraceIterator_GetPrevious().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.7 APITraceIterator_PeekNext()

Prototype

```
APITraceIterator_PeekNext(APITraceIterator *api_trace_iterator,
                           APITracePacket *api_trace_packet)
```

Description

It returns next packet of iterator without moving the iterator forward.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

api_trace_packet: Previous packet container.

Table 73: Error codes for APITraceIterator_PeekNext().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.8 APITraceIterator_PeekPrevious()

Prototype

```
APITraceIterator_PeekPrevious(APITraceIterator *api_trace_iterator,
                              APITracePacket *api_trace_packet)
```

Description

It returns previous packet of iterator without moving the iterator backward.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

api_trace_packet: Previous packet container.

Table 74: Error codes for APITraceIterator_PeekPrevious().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.9 APITraceIterator_GetAt()

Prototype

```
APITraceIterator_GetAt(APITraceIterator *api_trace_iterator, int index,
                        APITracePacket *api_trace_packet)
```

Description

It returns packet in the input index.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

index: Index of record. It is a zero-based index.

api_trace_packet: Packet container.

Table 75: Error codes for APITraceIterator_GetAt().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.
API_ERROR_INVALID_INDEX_OF_PACKET	15	Invalid index of packet.

5.9.10 APITraceIterator_GetCount()

Prototype

```
APITraceIterator_GetCount(APITraceIterator *api_trace_iterator, int *count)
```

Description

It returns the number of packets.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

count: Packet count.

Table 76: Error codes for APITraceIterator_GetCount().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.11 APITraceIterator_ToBack()**Prototype**

```
APITraceIterator_ToBack(APITraceIterator *api_trace_iterator)
```

Description

It moves the iterator pointer to the last packet.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

Table 77: Error codes for APITraceIterator_ToBack().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.9.12 APITraceIterator_ToFront()**Prototype**

```
APITraceIterator_ToFront(APITraceIterator *api_trace_iterator): void
```

Description

It moves the iterator pointer to the first packet.

Parameters

api_trace_iterator: Pointer to the trace iterator object.

Table 78: Error codes for APITraceIterator_ToFront().

API error code	Value	Description
API_ERROR_INVALID_OBJECT	2	The API object is not valid.
API_EXCEPTION	1	An exception occurred.

5.10 Examples

The following is a simple example for using the API to iterate through all the packets in a trace file. For complete examples, please refer to the API examples named "Trace" and "Project" which are provided with the Net Protocol Suite installer. This example is located in the directory.

"...\\API\\Examples\\Project" and "...\\API\\Examples\\Trace"

Appendix A

How to Contact Teledyne LeCroy

Send e-mail to Support	psgsupport@teledyne.com
Contact support	teledynelecroy.com/support/contact
Visit Teledyne LeCroy's web site	teledynelecroy.com
Tell Teledyne LeCroy	Report a problem to Teledyne LeCroy Support via e-mail by selecting Help > Tell Teledyne LeCroy from the application toolbar. This requires that an e-mail client be installed and configured on the host machine.

